



CABINET STYLE



LAZY SUSAN RECOMMENDED



Cabinet door is hinged and does not attach to lazy susan



Cabinet door is inset and must attach to lazy susan



FULL
CIRCLE

OR



D-SHAPED

- 1 DETERMINE CABINET STYLE
- 2 MEASURE INTERIOR CABINET OPENING AS SHOWN ABOVE
- 3 COMPARE MEASUREMENTS TO THE AVAILABLE PRODUCT SIZES/DIMENSIONS TO VERIFY FIT

NOTE: *This product can be added to new or existing cabinetry or can replace an older model.*

WILL IT FIT?