

CABINET LOCATION



Wall Cabinets (Upper)



Base Cabinets (Lower)

LAZY SUSANS

Diameter | Shape

16" (40.6 cm) ●

18" (45.7 cm) ● ◐

20" (50.8 cm) ● ◐

22" (55.9 cm) ● ◐

24" (61 cm) ● ◐ ◐

28" (71.1 cm) ● ◐ ◐


32" (81.3 cm) ● ◐

These size recommendations are based upon common standards for cabinetry. For custom applications, a trial installation is recommended.


SPECIFICATIONS

CABINET STYLE



LAZY SUSAN RECOMMENDED



Cabinet door is hinged and does not attach to lazy susan



Cabinet door is inset and must attach to lazy susan



OR



- 1 DETERMINE CABINET STYLE
- 2 MEASURE INTERIOR CABINET OPENING AS SHOWN ABOVE
- 3 COMPARE MEASUREMENTS TO THE AVAILABLE PRODUCT SIZES/DIMENSIONS TO VERIFY FIT

NOTE: *This product can be added to new or existing cabinetry or can replace an older model.*

WILL IT FIT?