

Congratulations!

You have purchased the finest carousel product available, the **Lazy Daisy® Susan**. For any questions or further information, please contact us at:



LAZY DAISY®
BY **REV-A-SHELF®**

2409 Plantside Dr. • Jeffersontown, KY 40299
(800) 626-1126 • www.rev-a-shelf.com

System 9

Pie-cut

Doors revolving
90-degree corner

Installation instructions for:

Article # LD-45-9168-8 (white) / LD-45-9268-8 (almond)

Base Cabinet
22" x 22"
55 x 55 cm

Tray diameter: 18" (45 cm)

Mounting height: 28 1/4" - 30 1/4"
(72 - 77 cm)

Minimum cabinet dimensions:

USA : 22"

EURO : 55 cm

a = 22"


a = 55 cm

b = 14"

b = 35 cm

c = 8"

c = 20 cm




18in PIE-CUT (2) Trays (LD-45-9168-8) (LD-45-9268-8)

System 9

Pie-cut

Doors revolving
90-degree corner

Parts list (14 pcs.)



System 9

Pie-cut

Doors revolving
90-degree corner

Mounting Instructions

1. Prepare **Top tray** by inserting **Top tray cover cap** and **Top tray positioning cap**.
2. Prepare **Bottom tray** by inserting **Bottom tray cover cap** and **Bottom tray positioning cap**.
3. Insert **Tube** through **Top tray**, **Top tray support ring** and **Bottom tray**.
4. Mount **Bottom mounting bracket** into cabinet using template provided.
5. Drill pilot holes for **Top mounting bracket** using template provided.
6. Place complete unit including **Top mounting bracket** into cabinet.
7. Mount **Top mounting bracket** to cabinet top.
8. Select desired top tray hole position and insert **Top tray securing pin** into tube.
9. Mount doors to both the **top and bottom trays**.
10. Adjust **Bottom mounting bracket** if necessary (see page 4).

System 9

Pie-cut

Doors revolving
90-degree corner


Door Adjustment

1. Door alignment

- Open doors so that one side of the bottom mounting bracket can be seen. With a pencil, mark the original position of the bottom mounting bracket. Insert a screw into the large hole on the end of the bracket (When inserting the screw, place it off-center in the direction of desired adjustment). Take out the original fixing screw. Repeat on the other side.
- Loosen the screws over the large holes and carefully rotate the bracket to the left or to the right, depending on which way the doors need to go.
- Tighten the screws and close doors to check alignment.
- Once door alignment is complete, re-insert fixing screws into one of the small holes.

CLEANING AND LUBRICATION

Clean as needed with mild soap and lukewarm water. Any common household lubricant is acceptable.



OTHER PRODUCTS

We offer a full line of cabinet organizers which compliment this system. For more information, contact your distributor or our customer service specialist on our toll-free number, 800-626-1126.

Pull-Out Waste Bin



Wire Bottom Blind Corner System



REV-A-LOCK[®]
Magnetic Cabinet
Locking System



Tip-Out Tray Systems



OXO Container
Base Organizer




PIE-CUT LAZY SUSAN



12400 Earl Jones Way
Louisville, KY 40299
Customer Service: 800-626-1126
www.rev-a-shelf.com

*Please keep this brochure
for future reference*


INSUFFICIENT SIDE CLEARANCE ADJUSTMENT



Step 1 Top Adjustment

Remove and save lockdown screws.

Loosen star washer screws to re-center pivot. Tighten, check and repeat if necessary.




Step 2 Bottom Adjustment

Rotate door to expose screws on bottom bracket


Remove and save lock down screws.

Loosen star washer screws to re-center pivot cam base (both sides). Tighten, check and repeat if necessary.




UNEVEN OR INCOMPLETE DOOR CLOSING ADJUSTMENT

(To center the doors correctly in the frame for proper clearance)



Step 1

Loosen clamp screw in white plastic housing (approx. 1 turn) to prepare for positioning adjustment.



Step 2

Rotate door counter-clockwise until white plastic housing has been latched into position with spring. A resistance to turning will be felt when the housing reaches the latched position and may be accompanied at a click or latching sound.



Step 3

Rotate door slowly clockwise to exact front centered position but not pass it. Release door to check alignment. You may need to rotate door a little past center to allow for slight spring-back. If you rotate too far, go back to step 2 and repeat.

Step 4

SLOWLY rotate door counter-clockwise far enough so that clamp screw faces you again. Tighten clamp screw securely, being careful not to rotate white plastic housing out of position.

TOP/BOTTOM CLEARANCE ADJUSTMENT



Step 1

Remove polymer retainer clip.

Step 2

Turn adjustment wheel (located inside cut out portion of shaft) clockwise to raise shelf/door unit. One full turn raises door 1/32". After adjustment, be sure to replace retainer clip.

Note: If shelves are heavily loaded, lift lower shelf slightly to aid adjustment. Total adjustment 1/2".

Note: When adjustments are completed, be sure to securely tighten all adjustment screws in housing, shaft bushing and tray adjustment screws. If bracket lock down screws were removed, please re-install after all adjustments are made.

Tools required for adjustments:
Phillips Screwdriver